

# Wind Chime Support Line Adjustment Jig

After you have decided on the alignment configuration, top, center or bottom; scribe a mark on a scrap piece of wood or cardboard for the reference point, top, center or bottom as shown below. Begin with the longest chime and select an appropriate length for the attachment line from the chime to the support point, and locate either nail or a pencil mark at that location on the template. Place the longest chime on the template and secure with tape, a clamp or maybe lay a book on it. Stretch the line up to the mark or nail and tie a loop or a knot to mark the attachment location. Repeat with the remainder of the chime set using the scribed reference mark. For center aligned chimes attaché a small piece of masking tape to the center of the chime and scribe the center alignment location.

